

# Fence panels measuring guide – On Blockwork

\*\*This guide is only applicable if ground is rising along the opening


## A. How to measure fence panels around corners:

- Measure according to the proposed final panel position
- Subtract post sizes from your measurement
- Choose the width and quantity of panels required
- Panels that meet on corners need a post
- If panels are centered to blockwork, measure the panel path - always!



### Tips:

2 panels have 3 posts  
3 panels have 4 posts  
etc...  
And when panels change  
direction, a post is needed.



Need help?

Talk to us: [info@australianagates.com.au](mailto:info@australianagates.com.au) / 0413633776 / [australianagates.com.au](http://australianagates.com.au)

This is a guide only. We will not be responsible or liable for any misinterpretation, incorrect calculations and measurements taken.